
















NOUS
GARDEN




60 min.





NOUSGARDEN LOUNGE SET SANUR



 (A) 3X	 (B) 3X	 (C) 2X	 (D) 2X
 (E) 1X	 (F) 1X	 (G) 5X	 (H) 5X
 (I) 1X	 (J) 2X	 (K) 1X	 M6X40 (L) 30X
 M6X18 (M) 2X	 M6X32 (N) 4X	 M6X20 (O) 4X	 D6 (P) 40X
 (Q) 40X	 (R) 1X		




01



02



03






A 1X B 1X E 1X F 1X G 3X H 3X I 1X M 2X L 10X P 12X Q 12X R 1X	01 02 03 04
--	---




J		2X
K		1X
N		M6X32 4X
O		M6X20 4X
P		D6 8X
Q		8X
R		1X

01



02



Aandachtspunten:

- ◆ Draai de schroeven gelijkmatig en niet te hard aan.
- ◆ Reinigen van alle delen (ook arm en rug) kan met een vochtige doek met milde groene zeep.
- ◆ Bescherm tegen stof, vuil, regen, etc. met een hoes. Haalkussens zo mogelijk binnen. In winter bank binnen opslaan.