


NOUS











GARDEN



60 min.







NOUSGARDEN LOUNGE SET VALLERA

 A6PCS	 B1PCS	 C5PCS	 D15PCS
 E1PC	 F2PCS	 G1PC	 H1PC
 I4PCS	 M8*60 J30PCS	 M6*10 K8PCS	 M6*15 L2PCS
 M8PCS	 N4PCS	 O4PCS	 P4PCS
 S4 Q1PC	 S5 R1PC		



						MB*60								S5	
A	2PCS	D	5PCS	I	1PC	J	10PCS	N	1PC	O	1PC	P	1PC	R	1PC





A	B	C	D	I	J	N	O	P	R
2PCS	1PC	5PCS	5PCS	2PCS	10PCS	2PCS	2PCS	2PCS	1PC

①


②

③


④




5



6




7






								M6*10		M6*15				S4	
E	1PC	F	2PCS	G	1PC	H	1PC	K	8PCS	L	2PCS	M	8PCS	Q	1PC


1




2



3



4



Aandachtspunten:

- ◆ Draai de schroeven gelijkmatig en niet te hard aan.
- ◆ Reinigen van alle delen (ook arm en rug) kan met een vochtige doek met milde groene zeep.
- ◆ Bescherm tegen stof, vuil, regen, etc. met een hoes. Haalkussens zo mogelijk binnen. In winter bank binnen opslaan.