# Bergen 120 foil/foil

Assembly Instructions Please keep for future reference

816/2043

804/8002

803/4267

hygena

Dimensions

Width - 120cm

Depth - 59.5cm

Height - 199.8cm

816/2043 OAK
803/4267 WAL
804/8002 WHT

Tip : To prevent damage, we recommend that you build your unit on the carton(s) it was packed in.

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit: **www.argos-support.co.uk**
or email: **Help@ClickSpares.co.uk** (quoting your original order number)
Alternatively, call the Spares Helpline on: **0370 112 1928**
For any other queries please contact the Customer Helpline on: **0345 640 2020**

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

•To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

Please check you have all the panels listed below

Cabinet

1	Left side

(199.8 x 52.9cm)
P2972

2	Right side

(199.8 x 55.8cm)
P2971

3	Upright

(191.4 x 49cm)
P2973

4	Foldy back x2

(194 x 59cm)
BO3453.0960

5	Top/bottom x2

(117 x 51cm)
P1883

6	Shelf x2

(57.7 x 48.8cm)
P1886

7	Plinth x2

(117 x 5.2cm)
P7246

8	Segment x4

(61.3 x 65cm)
P3422

9	Segment middle x2

(61.3 x 65.1cm)
P3423

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

1/2

|		
A FK1005 — Confirmat screw x 4 *(5x40mm)*	**B** FK1011 — Locking screw x 18 *(5x24mm)*	**C** FK1400 — Screw x 79 *(4x15mm)*
D FK1309 — Screw x 4 *(4x12.5mm)*	**E** FK1300 — Euro screw x 24 *(6.3x11mm)*	**F** FK1515 — Nail x 60
G FK1052 — Double locking screw x 3 *(5x66.5mm)*	**H** FK1411 — Wood dowel x 8 *(8x30mm)*	**I** FK1012 — Large locking nut x 24 *(15x12mm)* — 15mm
J FK1248 — Corner connector, white x 4	**K** FK1217 — Hanger rail support, gray x 4	**L** FK1234 — Peg, brown x 2
M FK1235 — L-Bracket x 2	**N** FK1419 — Nail holder x 1	**O** FK1255 — Connecting plate x 4
P PM182330 — Hanger rail x 2 *(569mm)*	**Q** PM1729 — Top guide rail x 1 *(1168mm)*	**R** PM1725 — Bottom guide rail x 1 *(1168mm)*
S PM1619B — Door handle x 3 *(1952mm)*	**T** PM1619D — Brush x 3 *(1952mm)*	**U** PM1619C — Door trim x 1 *(1952mm)*
V FK1013 — Allen key x 1 *(3mm)* OR	**W** ZF99936 — Wall plug *(6mm)* and parkerscrew x 2	

Components - Fittings

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A

AA *ZF9995M* Screw x 2 *(M6x20mm)*	**AB** *ZF9995G* Euro screw x 24 *(6.3x12.5mm)*	**AC** *ZF9995J* Screw x 11 *(3.5x16mm)*
AD *ZF9995K* End stop x 2	**AE** *ZF9995L* Covercap x 2	**AF** *ZF9995P* Support left
AG *ZF9995Q* Support right	**AH** *ZF9995C* Top roller back door left	**AI** *ZF9995D* Top roller back door right
AJ *ZF9995A* Top roller front door right	**AK** *ZF9995B* Top roller front door left	**AL** *ZF9995F* Mounting plate guide x 4
AM *ZF9995H* Bottom guide back door x 2	**AN** *ZF9995E* Bottom guide front door x 2	**AO** *ZF9995U* Allen key *(5mm)*

Tools required

- Phillips screwdriver *(medium & large)*
- Flatblade screwdriver *(medium)*
- Piercer *(small)*
- 5mm Suitable drill bit
- 5mm Suitable drill bit
- Drill
- Spirit level
- Setsquare
- Stairs
- Small hammer
- Ruler/tape measure
- Scissors
- Eye protection (when using a hammer or drill)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

Cabinet assembly

**a:** Screw 9 locking screws **B** into the holes of the left side ⌑1⌑.

a:

b: Mount hanger rail support **K**, fasten with 1 screw **D**. Screw **D** into the board between two predrilled holes.

Mount Support left **AF** with two screws **AC**, aligning the bottom hole of **AF** with the hole on panel.

b:

Finished front edge

Assembly Instructions

Cabinet assembly

a: Screw 9 locking screws
B into the holes of the
right side 2 .

a:

Finished
front edge

b: Mount hanger rail
support K, fasten with 1
screw D. Screw D into
the board between two
predrilled holes.

Mount Support right AG
with two screws AC,
aligning the bottom hole of
AG with the hole on panel.

b:

Finished
front edge

Assembly Instructions

Cabinet assembly

a: Mount hanger rail support Ⓚ on the upright ③, fasten with screw Ⓓ. Screw Ⓓ into the board between two predrilled holes

a:

Finished
front edge

b: Turn over.

b:

180˚

c: Mount hanger rail support Ⓚ on the upright ③, fasten with screw Ⓓ. Screw Ⓓ into the board between two predrilled holes.

c:

Finished
front edge

Step 4

Cabinet assembly

Insert 6x Large locking nuts ❶ into the top/bottom ⑤. **2x**

Make sure the 'arrow' on ❶ is pointing towards the hole in the edge of the top ⑤.

2x

Finished front edge

Step 5

Insert 6x Large locking nuts ❶ into the shelf ⑥. **2x.**

Make sure the 'arrow' on ❶ is pointing towards the hole in the edge of the bottom ⑥.

2x

Finished front edge

Step 6

Insert 4x wooden dowels ❶ into the plinth ⑦. **2x.**

2x

Step 7

Cabinet assembly

Attach 2x top/bottom 5
with 4x confirmat screws
Ⓐ to the upright 3.
Use allenkey Ⓥ.

Finished
front edge

Finished
front edge

Finished
front edge

Step 8

Attach 2x the shelf 6 to
the upright 3 with 3x
double locking screws Ⓖ.

Use a screwdriver to turn
6x locking nuts clockwise
to lock.

Finished
front edge

Finished
front edge

Step 9

Cabinet assembly

Attach the left side 1
with 9x locking screws and
locking nuts to the top 5,
shelf 8 and the bottom 6.

Use a screwdriver to turn
9x locking nuts clockwise to
lock.

Finished
front edge

Step 10

Attach 2x the plinth 7
between the left site 1
and the right side 2.

Attach the right side 2
with 9x locking screws and
locking nuts to the top 5,
shelf 8 and the bottom 6.

Use a screwdriver to turn
9x locking nuts clockwise
to lock.

Finished
front edge

11

Step 11

Cabinet assembly
Attach 2x foldy back 4 to back of cabinet with the coloured surface facing the inside of the cabinet using 60x nails **F** and 22x screws **C**.

Use nail holder **N** to hold the nails **F** vertical and at correct distance as you secure the 2x foldy back 4. Nails **F** should be spaced about 150mm apart.

Important:
Cabinet MUST be 'square' when back is attached.

Step 12

Mount corner connector **J** with 2 screws **C** on the plinth 7 and bottom 6.

Stand up the unit!
2 people required to stand up unit.

## Step 13

Cabinet assembly

Position Top guide rail **Q** onto top 5, with the ends fitting into support left **AF** and support right **AG**.

Fix top guide **Q** rail with 5x screws **C** to the top/ bottom 5.

Step 14

Insert covercap **AE** into slots of top guide rail **Q**. Attach End stop **AD** to covercap **AE** with screw **AA**.

Use allen key **AO** to tighten screw **AA**.

Step 15

Cabinet assembly

Position the lip of bottom guide rail **R** onto the top of top/bottom 5 , fix with 5x screws **AC**.

Step 16

Place Hanger rail **P** onto hanger rail support **K**. 2x

Assembly Instructions

Step 17

Place cabinet

a: Before fixing the unit to the wall, use a spirit level to check if the base of this unit is level front-to-back and side-to-side in the three positions shown.

Use pegs L to square your unit. Knock peg L in, as far as you require, under the ends of the unit and then snap off flush with the panel.

SNAP!

b: Attach 2 L-bracket M with screw C to the top of the cabinet.

Use 2 wall plug and screw W to mount 2x L-Bracket M on the wall,

please see last page for more information.

Step 18

3 Segment slide door left

Mount door trim **U** with 2x screws **E** and 2x screws **C** on segment 8.

Note: there should be no gap between doorsegment 8 and door trim **U**.

Step 19

Mount segment middle 9 with 2x screws **E** and 2x screw **C** on door trim **U**. Mount segment 8 with 2x screws **E** and 2x screw **C** on door trim **U**.

Step 20

Mount door handle **S** on segment 8 and middle segment 9 with 2x screws **E** and 2x screws **C** on each segment.

**Note**: there should be no gap between doorsegment 8 and door handle **S**.

Step 21

3 Segment slide door left

Mount 2x connecting plate **O**, each with 2x screws **C** on segment ⬛8 and 2x screws **C** on middle segment ⬛9.

Remove protective film from door handle **S**. Stick 1x brush **T** onto door handle **S** by partially removing the cover from tape as brush is applied.

Remove protective film

Step 22

Mount Top roller back door left **AH** with 4x screws **AB** on segment ⬛8. Mount Top roller back door right **AI** with 4x screws **AB** on segment ⬛8.

Note: make sure before hanging the door, the locking mechanism on **AI** and **AH** is in the open position.

Step 23

3 Segment slide door left

Mount 2x mounting plate
guide AL , each with 2x
screws AB on segment 8 .

Note: Use the inner two
of the pre-drilled holes.

Step 24

Slide Bottom guide back
AM onto mounting plate
guide AL .

Assembly Instructions

Step 25

**Place left slide door**

2 People are required for step 8a and 8b.

a: Hook Top roller back door left AH and Top roller back door right AI on the lower rail of metal guide rail Q.

b: Align bottom guide back door AM with the top rail of bottom guide rail R, and push on the bottom of the door until you hear a click.

c: To prevent the door falling out the rail. Lock Top rollers back door AH and AI, by rotating the mechanism to the lock position.

a:

b:

CLICK

c:

19

Step 26

3 Segment slide door right

Mount door handle S with 2x screws E and 2x screws C on segment 8.

Note: there should be no gap between doorsegment 8 and door handle S.

Step 27

Mount segment middle 9 with 2x screws E and 2x screw C on door handle S. Mount segment 8 with 2x screws E and 2x screw C on door handle S.

Step 28

Mount door handle S on segment 8 and middle segment 9 with 2x screws E and 2x screws C on each segment.

**Note**: there should be no gap between doorsegment 8 and door handle S.

Assembly Instructions

Step 29

3 Segment slide door right

Mount 2x connecting plate **O**, each with 2x screws **C** on segment [8] and 2x screws **C** on middle segment [9].

Remove protective film from door handle **S**. Stick brush **T** onto door handle **S** by partially removing the cover from tape as brush is applied.

Remove protective film

Step 30

Mount Top roller front door left **AK** with 4x screws **AB** on segment [8].
Mount Top roller front door right **AJ** with 4x screws **AB** on segment [8].

Note: make sure before hanging the door, the locking mechanism on **AJ** and **AH** is in the open position.

Step 31

3 Segment slide door right

Mount 2x mounting plate guide AL , each with 2x screws AB on segment 8 .

Note: Use the inner two of the pre-drilled holes.

Step 32

Slide Bottom guide front AN onto mounting plate guide AL .

Step 33

Place right slide door

2 People are required for step 16a and 16b.

**a:** Hook Top roller front door left AK and Top roller front door right AJ on the top rail of metal guide rail Q.

b: Align bottom guide front door AN with the lower rail of bottom guide rail R, and push on the bottom of the door until you hear a click.

CLICK

c: To prevent the door falling out the rail. Lock Top rollers front door AK and AJ, by pushing the mechanism to the lock position.

A Guide to - Wall Mounting & Fixings

⚠ Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.

4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls

You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**

For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**

For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**

For use with walls stuck with plasterboard. The hamemr fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**

For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

⚠ **Care & Maintenance**

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.