


# Bergen 120 HG/HG

Assembly Instructions Please keep for future reference

808/4437

**hygena**



## Dimensions

Width - 120cm  
Depth - 59.5cm  
Height - 199.8cm

808/4437 HG WHITE

**Tip : To prevent damage, we recommend that you build your unit on the carton(s) it was packed in.**

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, please visit: [www.argos-support.co.uk](http://www.argos-support.co.uk)  
or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)  
Alternatively, call the Spares Helpline on: **0370 112 1928**  
For any other queries please contact the Customer Helpline on: **0345 640 2020**



# Safety and Care Advice

**Important** – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.


**Note:** if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels


For damaged or missing parts, please visit:  
[www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)

Please check you have all the panels listed below


**Cabinet**




**1** Left side  
 (199.8 x 52.9cm)  
 P2972




**2** Right side  
 (199.8 x 55.8cm)  
 P2971



**3** Upright  
 (191.4 x 49cm)  
 P2973



**4** Foldy back x2  
 (194 x 59cm)  
 BO3453.0960




**5** Top/bottom x2  
 (117 x 51cm)  
 P1883



**6** Shelf x2  
 (57.7 x 48.8cm)  
 P1886



**7** Plinth x2  
 (117 x 5.2cm)  
 P7246



**10** HG door x2  
 (195.2 x 61.3cm)  
 P3424

























# Components - Fittings

For damaged or missing parts, please visit:  
[www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

1/2

<b>A</b>  <small>FK1005</small> Confirmat screw x 4 (5x40mm)	<b>B</b>  <small>FK1011</small> Locking screw x 18 (5x24mm)	<b>C</b>  <small>FK1400</small> Screw x 63 (4x15mm)
<b>D</b>  <small>FK1309</small> Screw x 4 (4x12.5mm)	<b>E</b>  <small>FK1300</small> Euro screw x 24 (6.3x11mm)	<b>F</b>  <small>FK1515</small> Nail x 60
<b>G</b>  <small>FK1052</small> Double locking screw x 3 (5x66.5mm)	<b>H</b>  <small>FK1411</small> Wood dowel x 8 (8x30mm)	<b>I</b>  <small>FK1012</small> Large locking nut x 24 (15x12mm)
<b>J</b>  <small>FK1248</small> Corner connector, white x 4	<b>K</b>  <small>FK1217</small> Hanger rail support, gray x 4	<b>L</b>  <small>FK1234</small> Peg, brown x 2
<b>M</b>  <small>FK1235</small> L-Bracket x 2	<b>N</b>  <small>FK1419</small> Nail holder x 1	
<b>P</b>  <small>PM182330</small> Hanger rail x 2 (569mm)	<b>Q</b>  <small>PM1729</small> Top guide rail x 1 (1168mm)	<b>R</b>  <small>PM1725</small> Bottom guide rail x 1 (1168mm)
<b>S</b>  <small>PM1619B</small> Door handle x 3 (1952mm)	<b>T</b>  <small>PM1619D</small> Brush x 3 (1952mm)	<b>U</b>  <small>PM1619C</small> Door trim x 1 (1952mm)
<b>V</b>  <small>FK1013</small> Allen key x 1 (3mm)	<b>W</b>  <small>ZF99936</small> Wall plug (6mm) and parkerscrew x 2	




# Components - Fittings

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

2/2




<b>AA</b>  Screw x 2 (M6x20mm) ZF9995M	<b>AB</b>  Euro screw x 24 (6.3x12.5mm) ZF9995G	<b>AC</b>  Screw x 11 (3.5x16mm) ZF9995J
<b>AD</b>  End stop x 2 ZF9995K	<b>AE</b>  Covercap x 2 ZF9995L	<b>AF</b>  Support left ZF9995P
<b>AG</b>  Support right ZF9995Q	<b>AH</b>  Top roller back door left ZF9995C	<b>AI</b>  Top roller back door right ZF9995D
<b>AJ</b>  Top roller front door right ZF9995A	<b>AK</b>  Top roller front door left ZF9995B	<b>AL</b>  Mounting plate guide x 4 ZF9995F
<b>AM</b>  Bottom guide back door x 2 ZF9995H	<b>AN</b>  Bottom guide front door x 2 ZF9995E	<b>AO</b>  Allen key (5mm) ZF9995U

## Tools required



Ruler - Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1

### Cabinet assembly

**a:** Screw 9 locking screws **B** into the holes of the left side **1**.


**a:**



**b:** Mount hanger rail support **K**, fasten with 1 screw **D**. Screw **D** into the board between two predrilled holes.

**b:**

Mount Support left **AF** with two screws **AC**, aligning the bottom hole of **AF** with the hole on panel.




# Assembly Instructions

## Step 2

### Cabinet assembly

**a:** Screw 9 locking screws **B** into the holes of the right side **2**.


**a:**



**b:** Mount hanger rail support **K**, fasten with 1 screw **D**. Screw **D** into the board between two predrilled holes.

Mount Support right **AG** with two screws **AC**, aligning the bottom hole of **AG** with the hole on panel.

**b:**




# Assembly Instructions

## Step 3

### Cabinet assembly


**a:** Mount hanger rail support **(K)** on the upright **[3]**, fasten with screw **(D)**. Screw **(D)** into the board between two predrilled holes

**a:**




**b:** Turn over.

**b:**



**c:** Mount hanger rail support **(K)** on the upright **[3]**, fasten with screw **(D)**. Screw **(D)** into the board between two predrilled holes.

**c:**



# Assembly Instructions


## Step 4

### Cabinet assembly

Insert 6x Large locking nuts **1** into the top/bottom **5**. **2x**

Make sure the 'arrow' on **1** is pointing towards the hole in the edge of the top **5**.

**2x**




## Step 5

Insert 6x Large locking nuts **1** into the shelf **6**. **2x**.

Make sure the 'arrow' on **1** is pointing towards the hole in the edge of the bottom **6**.


**2x**



## Step 6

Insert 4x wooden dowels **J** into the plinth **7**. **2x**.

**2x**




# Assembly Instructions

## Step 7

### Cabinet assembly


Attach 2x top/bottom **5** with 4x confirmat screws **A** to the upright **3**.  
Use allenkey **V**.



## Step 8

Attach 2x the shelf **6** to the upright **3** with 3x double locking screws **G**.

Use a screwdriver to turn 6x locking nuts clockwise to lock.





# Assembly Instructions

## Step 9

### Cabinet assembly

Attach the left side **1** with 9x locking screws and locking nuts to the top **5**, shelf **8** and the bottom **6**.

Use a screwdriver to turn 9x locking nuts clockwise to lock.





## Step 10

Attach 2x the plinth **7** between the left side **1** and the right side **2**.

Attach the right side **2** with 9x locking screws and locking nuts to the top **5**, shelf **8** and the bottom **6**.

Use a screwdriver to turn 9x locking nuts clockwise to lock.



# Assembly Instructions

## Step 11






### Cabinet assembly

Attach 2x foldy back **4** to back of cabinet with the coloured surface facing the inside of the cabinet using 60x nails **F** and 22x screws **C**.

Use nail holder **N** to hold the nails **F** vertical and at correct distance as you secure the 2x foldy back **4**. Nails **F** should be spaced about 150mm apart.




**Important:**  
Cabinet **MUST** be 'square' when back is attached.




## Step 12

Mount corner connector **J** with 2 screws **C** on the plinth **7** and bottom **6**.



**Stand up the unit!**  
**2 people required to stand up unit.**







# Assembly Instructions

## Step 13

### Cabinet assembly

Position Top guide rail **Q** onto top **5**, with the ends fitting into support left **AF** and support right **AG**.





Fix top guide **Q** rail with 5x screws **C** to the top/bottom **5**.



## Step 14

Insert covercap **AE** into slots of top guide rail **Q**. Attach End stop **AD** to covercap **AE** with screw **AA**.

Use allen key **AO** to tighten screw **AA**.




# Assembly Instructions

## Step 15


### Cabinet assembly

Position the lip of bottom guide rail **R** onto the top of top/bottom **5**, fix with 5x screws **AC**.



## Step 16

Place Hanger rail **P** onto hanger rail support **K**. 2x





# Assembly Instructions

## Step 17

### Place cabinet

**a:** Before fixing the unit to the wall, use a spirit level to check if the base of this unit is level front-to-back and side-to-side in the three positions shown.


Use pegs **L** to square your unit. Knock peg **L** in, as far as you require, under the ends of the unit and then snap off flush with the panel.



**b:** Attach 2 L-bracket **M** with screw **C** to the top of the cabinet.

Use 2 wall plug and screw **W** to mount 2x L-Bracket **M** on the wall,

please see last page for more information.




# Assembly Instructions

## Step 18

### HG slide door left

Mount door trim **U** with 6x screws **E** and 6x screws **C** on HG door **10**.


**Note:** there should be no gap between HG door **10** and door trim **U**.



## Step 19

Mount door handle **S** on HG door **10** with 6x screws **E** and 6x screws **C**.

**Note:** there should be no gap between HG door **10** and door handle **S**.




# Assembly Instructions

## Step 20


### HG slide door left

Remove protective film from door handle **S**.  
Stick 1x brush **T** onto door handle **S** by partially removing the cover from tape as brush is applied.



## Step 21

Mount Top roller back door left **AH** with 4x screws **AB** on HG door **10**.  
Mount Top roller back door right **AI** with 4x screws **AB** on HG door **10**.



**Note:** make sure before hanging the door, the locking mechanism on **AI** and **AH** is in the open position.


# Assembly Instructions

## Step 22

### HG slide door left


Mount 2x mounting plate guide **AL**, each with 2x screws **AB** on HG door **10**.

**Note:** Use the inner two of the pre-drilled holes.



## Step 23

Slide Bottom guide back **AM** onto mounting plate guide **AL**.





# Assembly Instructions

## Step 24


**Place left slide door**

**2 People are required for step 8a and 8b.**


**a:** Hook Top roller back door left **AH** and Top roller back door right **AI** on the lower rail of metal guide rail **Q**.



**b:** Align bottom guide back door **AM** with the top rail of bottom guide rail **R**, and push on the bottom of the door until you hear a click.



**c:** To prevent the door falling out the rail. Lock Top rollers back door **AH** and **AI**, by rotating the mechanism to the lock position.




# Assembly Instructions

## Step 25

### HG slide door right

Mount door handle **S** with 6x screws **E** and 6x screws **C** on HG door **10**.


**Note:** there should be no gap between HG door **10** and door handle **S**.



## Step 26

Mount door handle **S** on HG door **10** with 6x screws **E** and 6x screws **C**.

**Note:** there should be no gap between HG door **10** and door handle **S**.






# Assembly Instructions

## Step 27

### HG slide door right


Remove protective film from door handle **S**.  
Stick brush **T** onto door handle **S** by partially removing the cover from tape as brush is applied.



## Step 28

Mount Top roller front door left **AK** with 4x screws **AB** on HG door **10**.  
Mount Top roller front door right **AJ** with 4x screws **AB** on HG door **10**.

**Note:** make sure before hanging the door, the locking mechanism on **AJ** and **AH** is in the open position.




# Assembly Instructions

## Step 29

### HG slide door right


Mount 2x mounting plate guide **AL**, each with 2x screws **AB** on HG door **10**.

**Note:** Use the inner two of the pre-drilled holes.



## Step 30

Slide Bottom guide front **AN** onto mounting plate guide **AL**.





# Assembly Instructions

## Step 31


Place right slide door

**2 People are required for step 16a and 16b.**


**a:** Hook Top roller front door left **AK** and Top roller front door right **AJ** on the top rail of metal guide rail **Q**.



**b:** Align bottom guide front door **AN** with the lower rail of bottom guide rail **R**, and push on the bottom of the door until you hear a click.



**c:** To prevent the door falling out the rail. Lock Top rollers front door **AK** and **AJ**, by pushing the mechanism to the lock position.



# A Guide to - Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: General rule:** Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.